## **TECHNICAL SPECIFICATIONS**

## Off Camera Shoe Cord OC-E4A

MOUNTING FOOT

Multi-function

Number of contacts 15 Locking pins 2

Attachment method Lever with locking mechanism

Dust and water resistance Supported

MOUNTING SHOE

Contacts for 21-pin contact multi-function shoe

Contacts for conventional accessory Not provided

This product can also be used with Multi-Function Shoe Adapter AD-E1 to connect conventional accessories

Locking pins

Dust and water resistance Supported

AUDIO

Audio supported Channels

MISCELLANEOUS

Tripod socket 1/4 (ISO 1222)

Powered by camera Power source Incorporates a power line.

Power is not supplied for some connected accessories, such

DIMENSIONS

Camera connector W x H x D 38.8 x 36.7 x 47.4mm Accessory connector W x H x D 34.8 x 35.1 x 47.4mm

Cord Length / Diameter Approx. 80cm / Approx. 6.3mm

Approx. 150g Weiaht Working temperature 0-45°C Working Humidity

**ACCESSORIES** 

Supplied (Shoe) Cover - Foot

(Shoe) Cover - shoe

Canon Inc. canon.com Canon Europe canon-europe.com English edition Canon Europa NV 2023

